


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

NOYABRSK, RUSSIA

NOYABRSK

RNAV RWY 19

TRANSITION
LEVEL : **1**



- 1** TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL060 when QNH is less than 977 hPa (733mm mercury column).

WARNING

Flights over the city below 2500' / (635) are PROHIBITED.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).