


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

YUZHNO-SAKHALINSK, RUSSIA


KHOMUTOVO

RWY 01

TRANSITION
LEVEL : ①



③ PZ - 90.02 coordinates
PZ - 90.11 coordinates



RADAR TOWER 120.600
122.000

② CAT C, D ACFT
③ CAT A, B ACFT
④ Only for Russian users of airspace.

① TRANSITION LEVEL:
- FL070 when atmospheric pressure is 758mm mercury column or above;
- FL080 when atmospheric pressure is less than 758mm and is 731mm mercury column or above;
- FL090 when atmospheric pressure is less than 731mm mercury column.

WARNING
To provide the longitudinal separation the TWR controller (Yuzhno-Sakhalinsk - Radar controller) can remove the base turn initial point within 30km from ARP.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: New chart