


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : FL080

VLADIVOSTOK, RUSSIA
KNEVICH
RNAV RWY 25L



Restricted areas, active by NOTAM, are published in AIP ENR 5 section, AD 2.1 UHWW-57.

RADAR 123.400
TOWER 119.500

WARNING
Crossing altitudes for exit points of AWY are as directed by ATC.
② The restriction is not applicable to flights carried out according to SID and approach charts of VLADIVOSTOK/Knevichi AD.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES