


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: **FL050**

ANAPA, RUSSIA
VITYAZEVO
RNAV RWY 04



ANAPA KRUG **118.700**
ANAPA START **119.800**

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES