


AREA CHART - ICAO

ARRIVAL, DEPARTURE ROUTES

KRASNODAR, RUSSIA

PASHKOVSKIY



APPROACH Sector EAST 129.600  
Sector WEST 127.700

See ENR 4.1 for coordinate system of radio navigation aids.

① Only for Russian users.  
⑥ FL are AVBL on co-ordination with ATS unit.

All areas, active by NOTAM, are not shown on the area chart, these areas are published in AIP ENR 5 part and on page AD 2.1 URKK-56.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES AND ELEVATIONS IN FEET  
DISTANCES IN KILOMETRES