

AERODROME GROUND
MOVEMENT CHART - ICAO

SIVKAR START 124.600


SYKTYVKAR, RUSSIA

SYKTYVKAR

+18°



TERMINAL



Not to scale

APRON:

Surface: Asphalt-Concrete

Strength:

Stands: 1A, 1B, 2, 8-10 - PCN 28/R/B/X/T
4-6, 6A - PCN 30/R/B/X/T
7, 11-18 - PCN 37/F/D/X/T
19 - PCN 47/F/D/X/T

TAXIWAYS:

Width: A - 20m

Surface: A - Asphalt-Concrete

Strength: A - PCN 51/F/D/X/T

WARNING:

1. RWY 36/18 is AVBL for flight operations of Mi-2, Mi-8 HEL, flights operations in sector 200°-350° (over the city) are PROHIBITED.
2. Taxiing of Mi-2, Mi-8 HEL into/out of stands 15-18 is permitted through stand 19 in accordance with the marking.
3. AD does not provide arrival/departure of HEL on skid landing gear.

CHANGE: WARNING