


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

ORENBURG, RUSSIA
ORENBURG
RWY 08

TRANSITION
LEVEL: ①



RADAR 120.400
TOWER 128.000

WARNING

STAR RONIB 5E shall be executed by coordination with ATS unit.

① TRANSITION LEVEL:

- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES