


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: ①

ORENBURG, RUSSIA
ORENBURG
RWY 08/26



RADAR 120.400
TOWER 128.000

WARNING

STAR RONIB 5G, STAR PIMAM 5G shall be executed by coordination with ATS unit.

① **TRANSITION LEVEL:**

- FLO40 when QNH is 1013 hPa (760mm mercury column) or above;
- FLO50 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FLO60 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES

CHANGE: New chart