


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

ORENBURG, RUSSIA
ORENBURG
RNAV RWY 08

TRANSITION
LEVEL: 1



RADAR TOWER
120.400
128.000

WARNING
STAR GOGIN 5A, RONIB 5A shall be executed by coordination with ATS unit.

- 1** TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES

CHANGE: New chart