


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: **1**

YAKUTSK, RUSSIA
YAKUTSK
RNAV (GNSS) RWY 23L



1 TRANSITION LEVEL:
- FL050 when QFE is 751mm mercury column or above;
- FL060 when QFE is 724mm mercury column or above but less than 751mm mercury column;
- FL070 when QFE is less than 724mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES