


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION ALT: **4000'**
TRANSITION HGT: **(1050)**

BLAGOVESHCHENSK, RUSSIA
IGNATYEVO
RNAV RWY 36



TOWER 127.200

WARNING

When restricted area UHR1398 is active, utilization of all routes - by coordination with ATS unit.

The minimum climb gradients (required due to the airspace structure only) are as follows:

- 4.1% for AMERA 1Z up to FL070,
- 3.8% for SIMLI 1Z up to FL060,
- 4.8% for WZ 1Z up to FL070

or climbing by ATS unit instruction.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET AND METRES
ELEVATIONS IN FEET AND METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: Heading, HGT