


TRANSITION LEVEL : **1**



APPROACH **120.500**  
START **124.000**

- 1** TRANSITION LEVEL:
- FL080 when QFE is 760mm mercury column (1013 hPa) or above;
  - FL090 when QFE is 733mm mercury column (977 hPa) or above, but less than 760mm mercury column (1013 hPa);
  - FL100 when QFE is less than 733mm mercury column (977 hPa).

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES, ELEVATIONS IN METRES AND **FEET**  
DISTANCES ARE IN KILOMETRES

Alt set: -QFE(QNH on req);  
-mm(hPa on req).