

STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

BRATSK, RUSSIA

BRATSK

RWY 12

TRANSITION
LEVEL: ①



APPROACH 118.100
TOWER 121.800

- ① TRANSITION LEVEL:
- FL060 when QFE is 715mm mercury column or above;
 - FL070 when QFE is 688mm mercury column or above but less than 715mm mercury column;
 - FL080 when QFE is less than 688mm mercury column.

② Only for Russian users.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

CHANGE: LOM, MSH