


KRASNODAR, RUSSIA

AREA CHART - ICAO

ARRIVAL, DEPARTURE ROUTES

PASHKOVSKIY



APPROACH Sector EAST	129.600
Sector WEST	127.700
RADAR	121.300
TOWER	118.200

See ENR 4.1 for coordinate system of radio navigation aids.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES

CHANGE: New chart