


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

KRASNODAR, RUSSIA
PASHKOVSKIY
RNAV RWY 05R

TRANSITION
LEVEL: **1**



APPROACH Sector WEST **127.700**
Sector EAST **129.600**
RADAR **121.300**
TOWER **118.200**

2 URP132
500m/1600' AGL
GND

1 TRANSITION LEVEL:
- FL060 when QNH is 977 hPa (733mm mercury column) or above;
- FL070 when QNH is 941 hPa (706mm mercury column) or above,
but less than 977 hPa (733mm mercury column).

NOTE
ATC using facilities for surveillance of ACFT to avoid
restricted area URR522 is required for holding over NDB SM.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: Heading, URP, URR, URD