


AREA CHART - ICAO

ARRIVAL, DEPARTURE  
AND TRANSIT ROUTES

GROZNY, RUSSIA

SEVERNY



GROZNY TOWER **120.200**  
 GROZNY START **119.000**

**1** Only for Russian users.

BEARINGS AND TRACKS ARE MAGNETIC  
 ALTITUDES, HEIGHTS AND ELEVATIONS IN METRES  
 DISTANCES IN KILOMETRES

CHANGE: New chart