


STANDARD DEPARTURE CHART  
INSTRUMENT (SID) - ICAO

YEKATERINBURG, RUSSIA  
KOLTSOVO  
RWY 08L

TRANSITION ALT: **4000'**  
TRANSITION HGT: **(1000)**



KOLTSOVO START **124.300**  
KOLTSOVO RADAR **118.700**  
KOLTSOVO APPROACH **125.900**

**WARNING**  
There are close-in obstacles.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES AND ELEVATION IN **FEET**  
HEIGHTS IN METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).