


**VISUAL
APPROACH
CHART - ICAO**

KOLTSOVO RADAR	118.700
KOLTSOVO START	124.300

YEKATERINBURG, RUSSIA
KOLTSOVO
RWY 08L/26R, 08R/26L



- 1** **TRANSITION LEVEL:**
- FL050 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL060 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL070 when QNH is less than 977 hPa (733mm mercury column).

CHANGE: OBST