

MOSCOW, RUSSIA

VNUKOVO
VNUKOVO 1 APRONSTANDS
AIRCRAFT PARKING
CHART - ICAO(1) – AVBL for PRKG of ACFT facing the Terminal (3) – AVBL for PRKG of ACFT facing TWY B5
(2) – AVBL for PRKG of ACFT with a tail to the Terminal (4) – AVBL for PRKG of ACFT facing TWY M1

ACFT types	STANDS								
A-300-600, A-300-600R	1-5, 14, 15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66	B737-600, B737-700	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-51, 57-66	Challenger 300, 601-3A/ER, 604, 605, 850 CRJ-100-200, CRJ-200	All stands All stands	Gulfstream 100, 200, IV Gulfstream 350, Gulfstream 450	All stands 1-14, 14A, 14B, 15, 15A, 15B, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41-56, 56A, 57-66	II-62	1-5, 14, 15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66
A-310-222, A-310-200,-300	1-6, 14-23, 32-38, 23A, 24A, 26A, 31A, 34A, 38A, 38B, 38C, 39, 40, 47- 51, 62-66	B737-600W, B737-700W, B737-700BBJ	1-6, 8, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26A, 27, 28, 30, 31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-51, 57-66	DC-9-10, DC-9-20	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-52, 57-66	Gulfstream 5, Gulfstream 500, Gulfstream 550	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66	II-76	2, 14, 15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66
A-318, A-319	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-51, 57-66	B737-800	1-6, 8, 10-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	DC-9-30	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	Hawker 1000, 400, 700, 750, 800XP, Hawker 125-700	All stands	II-86	1-5, 14, 15, 18, 18A, 19, 22, 23, 23A, 24A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66
A-320, A-320-210	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	B737-800W, B737-800BBJ2	1-6, 8, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26A, 27, 30, 31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	DC-9-40	1-6, 8, 10-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	Learjet 31, 35, 40, 45, 55, 60	All stands	II-96-300, II-96-400T	2, 14, 15, 18A, 19, 22, 23, 23A, 24A, 31A, 32, 32E, 34A, 38A, 38C, 40, 63- 66
A-321-100, A-321-200	1-6, 10, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	B737-900, B737-900ER	1-6, 10, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	DC-9-50	1-6, 10, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	MD-82, MD-83, MD-88	1-6, 10, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	SSJ-100 (RRJ-95)	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66
A-330-200, -300, A-340-200, -300, -300E, -8000	2, 14, 15, 18A, 19, 22, 23, 23A, 24A, 31A, 32, 32E, 34A, 38A, 38C, 40, 63- 66	B737-900W, B737-900ERW	1-6, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26A, 27, 30, 31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	DHC-8 Q200	1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41, 42-56, 56A, 57-66	Premier 1 SAAB 340 SAAB 2000	All stands All stands 1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41-56, 56A, 57-66	Tu-134	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66
A-340-500	2, 14, 15, 18A, 22, 23, 23A, 24A, 31A, 32, 32E, 34A, 38A, 38C, 40, 63-66	B737-900W, B737-900ERW	1-6, 12-18, 18A, 19-23, 23A, 24, 24A, 25, 26A, 27, 30, 31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	DHC-8 Q300	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66	An-12	1-6, 12-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-45, 47-51, 62-66	Tu-154	1-6, 12-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66
A-340-600	23, 23A	B747-100, -400, B777-200, -200LR, -300, -300LR, B777F	2, 14, 15, 18A, 22, 23, 23A, 24A, 31A, 32, 32E, 34A, 38A, 38C, 40, 63-66	DHC-8 Q400	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-52, 57-66	An-28 An-72, An-74	All stands, except 19 1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-51, 57-66	Tu-204, Tu-214	1-6, 12, 14-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66
A-350-900	2, 14, 15, 18A, 22, 23, 23A, 24A, 31A, 32, 34A, 38A, 40, 63-66	B747-8	32, 34A, 38A, 38C	Embraer 120, 135 Embraer 145	All stands 1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41-56, 56A, 57-66	An-140	1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41, 42-56, 56A, 57-66, 67, 67A, 68, 68A, 69, 69A, 70, 70A, 71, 71A	Yak-40	1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41, 42-56, 56A, 57-66
A-380-700, -800	23A, 38A, 38C	B757-200, B757-200 Freighter	1-6, 12-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62- 66	Embraer 170/175	1-5, 12-15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66	An-148, An-24	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66	Yak-42	1-6, 8, 11-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66
B737 MAX 9	1-6, 12-23, 23A, 26A, 31A, 32-40, 34A, 37A, 38A, 42, 47-51, 62-66	B757-300	1-5, 12-15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 38, 38A, 38B, 38C, 39, 39A, 40, 63-66	Embraer 190 and its modifications, Embraer 195, Embraer 195LR	1-6, 8, 10-18, 18A, 19-23, 23A, 24, 24A, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	An-22	2, 14, 15, 18A, 19, 22, 23, 23A, 24A, 31A, 32, 32E, 34A, 38A, 38C, 40, 63- 66		
ATR-42-300, -320, -500	All stands	B777-200, -200LR, FB	18, 19	Falcon 10, 20, 50, 2000, 7X, 900	All stands	An-124-100	23A, 32, 32E, 34A, 38A, 38C		
ATR-72-200, ATR-72-210, ATR-72-500	1-14, 14A, 14B, 15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27- 31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 40A, 40B, 41, 42-56, 56A, 57-66, 67, 67A, 68, 68A, 69, 69A, 70, 70A, 71, 71A	B777-300, -300ER	2, 14, 15, 18A, 22, 23, 23A, 24A, 31A	Fokker 100	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 46-51, 57-66	II-114	1-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66		
B707, B707-320B	1-5, 14, 15, 17, 18, 18A, 19, 22, 23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36-38, 38A, 38B, 38C, 39, 39A, 40, 63-66	BAe-125-700, -800	All stands	Fokker 70	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66	II-18	1-6, 12-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66		
B707-120, B707-120B	1-6, 12, 14-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	BD-700 Global Express	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66	Global 5000	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C, 32D, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40-56, 56A, 57-66				
B727-200	1-6, 10, 12-18, 18A, 19-23, 23A, 24, 24A, 26, 26A, 27, 30, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42, 47-51, 62-66	C-130H, C-130J	1-6, 12, 14-18, 18A, 19-23, 23A, 24A, 26A, 31A, 32, 32E, 33, 33A, 34, 34A, 34B, 35, 35A, 36, 37, 37A, 38, 38A, 38B, 38C, 39, 39A, 40, 42-45, 47-51, 62-66						
B737-200, B737-500	1-15, 15A, 16-18, 18A, 19-23, 23A, 24, 24A, 25, 26, 26A, 27-31, 31A, 32, 32A, 32B, 32C,								