

AIRCRAFT PARKING/DOCKING  
CHART - ICAO


APRON ELEV  
680'

TOWER 118.300  
GROUND 1 120.450

MOSCOW, RUSSIA

VNUKOVO

PZ - 90.02 coordinates



STAND NR	LATITUDE (N)	LONGITUDE (E)
501	55 35 50.08	037 17 44.45
502	55 35 50.77	037 17 47.59
503	55 35 51.48	037 17 50.70
504	55 35 52.06	037 17 53.38
505	55 35 52.65	037 17 56.05
506	55 35 52.92	037 17 58.51
507	55 35 45.81	037 17 47.37
508	55 35 46.40	037 17 50.06
509	55 35 46.98	037 17 52.72
510	55 35 47.45	037 17 55.05

Not to scale

**STANDS:**

Strength:  
501-510 - PCN 51/R/B/W/T

**STANDS:**

502  
501, 503-505, 507-509  
506, 510

**WARNING**

Taxiing into/out of stands - by towing.

**ACFT types:**

Il-96 and class below  
Tu-214 and class below  
An-148 and class below