


ATC SURVEILLANCE MINIMUM  
ALTITUDE CHART - ICAO

ELEV  
165 / 50m

TRANSITION ALT: 3000'  
TRANSITION HGT: (865)

STREZHEVOY, RUSSIA

STREZHEVOY



KARAVAY RADAR 120.700

**WARNING:**

1. The chart may only be used for cross-checking of altitudes assigned while the aircraft is identified under radar control.
2. When vectoring is carried out under low-temperature conditions, minimum vectoring altitudes for IFR flight must be corrected by altimeter temperature correction.

COMMUNICATION FAILURE: In accordance with the procedures described in AIP.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES IN FEET  
HEIGHTS IN METRES  
ELEVATIONS IN FEET AND METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).