


VISUAL  
APPROACH  
CHART - ICAO

INFORMATSIYA 126.000

BOVANENKOVO, RUSSIA  
BOVANENKOVO  
RWY 10/28



① TRANSITION LEVEL:

- FL060 when QNH is 1013 hPa (760mm mercury column) or above;
- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL080 when QNH is less than 977 hPa (733mm mercury column).