


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

BOVANENKOVO, RUSSIA
BOVANENKOVO
RNAV RWY 10

TRANSITION ALT: 4000'



BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
HEIGHTS IN METRES
ELEVATIONS IN FEET AND METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: New chart