


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

BOVANENKOVO, RUSSIA
BOVANENKOVO
RNAV RWY 28

TRANSITION ALT: 4000'



INFORMATSIYA 126.000

WARNING

The minimum climb gradients required due to the airspace structure:

- 3.7% up to FL060 for SID ATNIR 2E;
- 4.4% up to FL060 for SID UNKOR 2E;
- 4.7% up to FL060 for SID RENLA 2E;
- 3.7% up to FL060 for SID POKAR 2E.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
HEIGHTS IN METRES
ELEVATIONS IN FEET AND METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).