


ATC SURVEILLANCE MINIMUM  
ALTITUDE CHART - ICAO

ELEV  
219'

TRANSITION ALT: 5100'

SALEKHARD, RUSSIA

SALEKHARD



KRUG 120.800  
START 118.600

**WARNING:**

1. The chart may only be used for cross-checking of altitudes assigned while the aircraft is under radar control.
2. When vectoring is carried out under low-temperature conditions, minimum vectoring altitudes for IFR flight must be corrected by altimeter temperature correction.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES AND ELEVATIONS IN FEET  
DISTANCES IN KILOMETRES

Alt set: -QNH(QNH on req);  
-hPa (mm on req).

CHANGE: New chart