



BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
ELEVATIONS IN FEET AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

CRUISE
START 120,800
118,600

1 TRANSITION LEVEL:
- FLO70 when QNH is 984 hPa (738mm mercury column) or above;
- FLO80 when QNH is 948 hPa (711mm mercury column) or above,
but less than 984 hPa (738mm mercury column);
- FLO90 when QNH is less than 948 hPa (711mm mercury column).

All set: -QNH/QNH on req.);
-hPa (mm on req).)

Federal Air Transport Agency

CHANGE: New chart