


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

BELOYARSKIY, RUSSIA
BELOYARSKIY
RWY 16/34

TRANSITION
LEVEL: 1



BERYOZOV0 APPROACH 132.100
RADAR 120.900
START 118.100

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: New chart