

AERODROME  
CHART - ICAO

ARP  
65°28'56"N  
072°41'54"E


ELEV  
15m / 49'

START 120.600

NADYM, RUSSIA


NADYM

PZ - 90.11 coordinates



**WARNING**

RWY edge lights are located at DIST up to 2.5m from RWY edges, the height of fixture of RWY, TWY, MAIN TWY lighting is 0.30m. Take-off and landing of HEL in sector 123°-138° are PROHIBITED.




RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
14	157°14'00"	65°29'36"N 072°41'14"E	PCN 40 /R/A/X/T
32	337°15'13"	65°28'17"N 072°42'34"E	

ELEVATIONS AND FEET  
DIMENSIONS IN METRES  
BEARINGS ARE MAGNETIC


CHANGE: VAR. ELEV

NADYM


MARKING AIDS RWY 14 / 32 AND EXIT TWY



LIGHTING AIDS RWY 14 / 32 AND EXIT TWY



**WARNING**  
Runway edge lights are installed at 2.5m from RWY edges, height of RWY, TWY, MAIN TWY light fixtures is 0.30m.



DIMENSIONS IN METRES

CHANGE: NIL