
AERODROME GROUND MOVEMENT CHART - ICAO START **120.600**ZEMLYA **118.900** 

NADYM, RUSSIA

NADYM



## TAXIWAYS:

Width:

Surface: MAIN TWY M, G1-G4 - Precast Reinforced Concrete

Strength: G1, G2, MAIN TWY M - PCN 40/R/A/X/T G3 - PCN 44/R/A/X/T

G3 - PCN 44/R/A/X/T G4 - PCN 22/R/A/X/T

G4 - PCN 2 G1, MAIN TWY M - 20m

G2 - 16m

G3 - 22m

64 - 14m

## WARNING:

- Take-off/landing of HEL from/on helipads NR 1 and NR 2 in sector 123°-138° are PROHIBITED. Take-off/landing of HEL from/on helipads NR 1 and NR 2 are permitted along flight paths that exclude the possibility of overflying ACFT.
- Runway turn pads at RWY 14/32 thresholds and junction of TWY G1 and RWY are AVBL for ACFT turn.
- 3. All ACFT approved for operation at the aerodrome are permitted to turn on the runway.
- 4. When stand 36 is occupied, taxiing via MAIN TWY M segment from TWY G1 to TWY G2 is PROHIBITED.
- 5. Taxiing via MAIN TWY M from the apron to stand 36 by towing.