


ATC SURVEILLANCE MINIMUM
ALTITUDE CHART - ICAO

ELEV
212 / 65m

TRANSITION ALT: 5000'
TRANSITION HGT: (1400)

NOVY URENGOY, RUSSIA

NOVY URENGOY



RADAR TOWER	124.700 121.900
BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN FEET AND METRES HEIGHTS IN METRES DISTANCES IN KILOMETRES	
Alt set: - QNH (QFE on req); - hPa (mm on req).	

WARNING:

- The chart may only be used for cross-checking of altitudes assigned while the aircraft is under radar control.
- When vectoring is carried out under low-temperature conditions, minimum vectoring altitudes for IFR flight must be corrected by altimeter temperature correction by ATC.

COMMUNICATION FAILURE: In accordance with the procedures described in AIP.