


VFR
ARRIVAL
CHART

NOVY URENGOY, RUSSIA
NOVY URENGOY
RWY 27

TRANSITION
LEVEL: ①



RADAR 124.700
TOWER 121.900

① TRANSITION LEVEL:
 - FLO60 when QNH is 1013 hPa (760mm mercury column) or above;
 - FLO70 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FLO80 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
 ALTITUDES IN FEET
 ELEVATIONS IN FEET AND METRES
 HEIGHTS IN METRES
 DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
 -hPa(mm on req).