# STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : **FL080**

# VLADIVOSTOK, RUSSIA
KNEVICHI
RNAV RWY 07R




RADAR **123.400**
TOWER **119.500**

**WARNING**
Crossing altitudes for exit points of AWY are as directed by ATC.
❷ The restriction is not applicable to flights carried out according to SID and approach charts of VLADIVOSTOK/Knevichi AD.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS ARE IN METRES
DISTANCES ARE IN KILOMETRES

**CHANGE:** UHP321