STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : **by ATC** ❶

MOSCOW, RUSSIA
SHEREMETYEVO
RNAV RWY 06L, 06C, 06R



SHEREMETYEVO ARRIVAL	**127.700**	**135.900**	**118.100**	**126.600**	
SHEREMETYEVO TOWER	**118.700**	**120.700**	**131.500**	**119.300**	
MOSCOW APPROACH	**127.200**	**128.000**	**134.000**	**131.200**	**134.675**

❶ - FL110 when QNH is 1013 hPa (760mm mercury column) or above;
- FL120 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL130 when QNH is less than 977 hPa (733mm mercury column).

CHANGE: New chart

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN ***FEET***
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).