STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL: ❶

CHELYABINSK, RUSSIA
BALANDINO
RNAV RWY 09



APPROACH	**124.700**
RADAR	**133.200**
START	**125.200**

❶ TRANSITION LEVEL:
- FL070 when QNH is 1013 hPa (760mm mercury column) or above;
- FL080 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL090 when QNH is less than 977 hPa (733mm mercury column).

❷ Flights through prohibited area USP202 are allowed at FL050-FL330.
❸ LERTU 2C, UTABI 2C
❹ ASLIM 2C, LERDA 2C, LERTU 2C, UTABI 2C
❺ GERSI 2C, LUTAT 2C
❻ MSAAT/MSHAT is computed for surface air temperature at the aerodrome -35.5°C.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN *FEET*
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: New chart