STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 17

ABNIS 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на ABNIS с МПС 147° WN с набором FL060 или выше.

BAGOD 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на BAGOD с МПС 140° WN с набором FL060 или выше.

BALUS 1A

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на BALUS с МПС 214° WN с набором FL060 или выше.

DEDOR 1A

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 303° до захвата МПС 273° WN, далее на DEDOR с МПС 273° WN с набором FL060 или выше.

FADRI 1A

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 023° до захвата МПС 337° WN, далее на FADRI с МПС 337° WN с набором FL060 или выше.

GILAG 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 089° до захвата МПС 119° WN, далее на GILAG с МПС 119° WN с набором FL060 или выше.

INDIR 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 080° до захвата МПС 110° WN, далее на INDIR с МПС 110° WN с набором FL060 или выше.

NERDA 1A

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на NERDA с МПС 222° WN с набором FL060 или выше.

OGONI 1A

На МПУ 173° набор (200) или выше, далее на OGONI с МПС 176° WN с набором FL060 или выше.

PELIM 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 325° до захвата МПС 011° WN, далее на PELIM с МПС 011° WN с набором FL060 или выше.

PIROD 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 049° до захвата МПС 079° WN, далее на PIROD с МПС 079° WN с набором FL060 или выше.

RUSEB 1A

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 356° до захвата МПС 314° WN, далее на RUSEB с МПС 314° WN с набором FL060 или выше.

SUGIP 1A

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на SUGIP с МПС 128° WN с набором FL060 или выше.

ABNIS 1A

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 147° WN to ABNIS climbing to FL060 or above.

BAGOD 1A

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 140° WN to BAGOD climbing to FL060 or above.

BALUS 1A

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on QDR 214° WN to BALUS climbing to FL060 or above.

DEDOR 1A

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 303° MAG to intercept QDR 273° WN, then proceed on QDR 273° WN to DEDOR climbing to FL060 or above.

FADRI 1A

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 023° MAG to intercept QDR 337° WN, then proceed on QDR 337° WN to FADRI climbing to FL060 or above.

GILAG 1A

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 089° MAG to intercept QDR 119° WN, then proceed on QDR 119° WN to GILAG climbing to FL060 or above.

INDIR 1A

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 080° MAG to intercept QDR 110° WN, then proceed on QDR 110° WN to INDIR climbing to FL060 or above.

NERDA 1A

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on QDR 222° WN to NERDA climbing to FL060 or above.

OGONI 1A

Climb on track 173° MAG to (200) m or above, then proceed on QDR 176° WN to OGONI climbing to FL060 or above.

PELIM 1A

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 325° MAG to intercept QDR 011° WN, then proceed on QDR 011° WN to PELIM climbing to FL060 or above.

PIROD 1A

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 049° MAG to intercept QDR 079° WN, then proceed on QDR 079° WN to PIROD climbing to FL060 or above.

RUSEB 1A

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 356° MAG to intercept QDR 314° WN, then proceed on QDR 314° WN to RUSEB climbing to FL060 or above.

SUGIP 1A

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 128° WN to SUGIP climbing to FL060 or above.

STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 35

ABNIS 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на ДПРМ WN, далее на ABNIS с МПС 147° WN с набором FL060 или выше.

BAGOD 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на ДПРМ WN, далее на BAGOD с МПС 140° WN с набором FL060 или выше.

BALUS 1E

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на ДПРМ WN, далее на BALUS с МПС 214° WN с набором FL060 или выше.

DEDOR 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 195° до захвата МПС 273° WN, далее на DEDOR с МПС 273° WN с набором FL060 или выше.

FADRI 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот до захвата МПС 337° WN, далее на FADRI с МПС 337° WN с набором FL060 или выше.

GILAG 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на ДПРМ WN, далее на GILAG с МПС 119° WN с набором FL060 или выше.

INDIR 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на ДПРМ WN, далее на INDIR с МПС 110° WN с набором FL060 или выше.

NERDA 1E

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на ДПРМ WN, далее на NERDA с МПС 222° WN с набором FL060 или выше.

OGONI 1E

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на ДПРМ WN, далее на OGONI с МПС 176° WN с набором FL060 или выше.

PELIM 1E

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 041° до захвата МПС 011° WN, далее на PELIM с МПС 011° WN с набором FL060 или выше.

PIROD 1E

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 162° до захвата МПС 079° WN, далее на PIROD с МПС 079° WN с набором FL060 или выше.

RUSEB 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 277° до захвата МПС 314° WN, далее на RUSEB с МПС 314° WN с набором FL060 или выше.

SUGIP 1E

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на ДПРМ WN, далее на SUGIP с МПС 128° WN с набором FL060 или выше.

ABNIS 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to LOM WN, then proceed on QDR 147° WN to ABNIS climbing to FL060 or above.

BAGOD 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to LOM WN, then proceed on QDR 140° WN to BAGOD climbing to FL060 or above.

BALUS 1E

Climb on track 353° MAG to (200) m or above, turn RIGHT to LOM WN, then proceed on QDR 214° WN to BALUS climbing to FL060 or above.

DEDOR 1E

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 195° MAG to intercept QDR 273° WN, then proceed on QDR 273° WN to DEDOR climbing to FL060 or above.

FADRI 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to intercept QDR 337° WN, then proceed on QDR 337° WN to FADRI climbing to FL060 or above.

GILAG 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to LOM WN, then proceed on QDR 119° WN to GILAG climbing to FL060 or above.

INDIR 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to LOM WN, then proceed on QDR 110° WN to INDIR climbing to FL060 or above.

NERDA 1E

Climb on track 353˚ MAG to (200) m or above, turn RIGHT to LOM WN, then proceed on QDR 222˚ WN to NERDA climbing to FL060 or above.

OGONI 1E

Climb on track 353° MAG to (200) m or above, turn RIGHT to LOM WN, then proceed on QDR 176° WN to OGONI climbing to FL060 or above.

PELIM 1E

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 041° MAG to intercept QDR 011° WN, then proceed on QDR 011° WN to PELIM climbing to FL060 or above.

PIROD 1E

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 162° MAG to intercept QDR 079° WN, then proceed on QDR 079° WN to PIROD climbing to FL060 or above.

RUSEB 1E

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 277° MAG to intercept QDR 314° WN, then proceed on QDR 314° WN to RUSEB climbing to FL060 or above.

SUGIP 1E

Climb on track 353° MAG to (200) m or above, turn LEFT to LOM WN, then proceed on QDR 128° WN to SUGIP climbing to FL060 or above.

STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 17

ABNIS 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на ABNIS с МПС 150° W с набором FL060 или выше.

BAGOD 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на BAGOD с МПС 143° W с набором FL060 или выше.

BALUS 1B

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на BALUS с МПС 210° W с набором FL060 или выше.

DEDOR 1B

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 305° до захвата МПС 268° W, далее на DEDOR с МПС 268° W с набором FL060 или выше.

FADRI 1B

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 025° до захвата МПС 336° W, далее на FADRI с МПС 336° W с набором FL060 или выше.

GILAG 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 093° до захвата МПС 123° W, далее на GILAG с МПС 123° W с набором FL060 или выше.

INDIR 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 093° до захвата МПС 115° W, далее на INDIR с МПС 115° W с набором FL060 или выше.

NERDA 1B

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на NERDA с МПС 217° W с набором FL060 или выше.

OGONI 1B

На МПУ 173° набор (200) или выше, далее на OGONI с МПС 175° W с набором FL060 или выше.

PELIM 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 323° до захвата МПС 012° W, далее на PELIM с МПС 012° W с набором FL060 или выше.

PIROD 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 050° до захвата МПС 084° W, далее на PIROD с МПС 084° W с набором FL060 или выше.

RUSEB 1B

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 360° до захвата МПС 311° W, далее на RUSEB с МПС 311° W с набором FL060 или выше.

SUGIP 1B

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на SUGIP с МПС 132° W с набором FL060 или выше.

ABNIS 1B

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 150° W to ABNIS climbing to FL060 or above.

BAGOD 1B

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 143° W to BAGOD climbing to FL060 or above.

BALUS 1B

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on QDR 210° W to BALUS climbing to FL060 or above.

DEDOR 1B

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 305° MAG to intercept QDR 268° W, then proceed on QDR 268° W to DEDOR climbing to FL060 or above.

FADRI 1B

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 025° MAG to intercept QDR 336° W, then proceed on QDR 336° W to FADRI climbing to FL060 or above.

GILAG 1B

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 093° MAG to intercept QDR 123° W, then proceed on QDR 123° W to GILAG climbing to FL060 or above.

INDIR 1B

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 093° MAG to intercept QDR 115° W, then proceed on QDR 115° W to INDIR climbing to FL060 or above.

NERDA 1B

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on QDR 217° W to NERDA climbing to FL060 or above.

OGONI 1B

Climb on track 173° MAG to (200) m or above, then proceed on QDR 175° W to OGONI climbing to FL060 or above.

PELIM 1B

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 323° MAG to intercept QDR 012° W, then proceed on QDR 012° W to PELIM climbing to FL060 or above.

PIROD 1B

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 050° MAG to intercept QDR 084° W, then proceed on QDR 084° W to PIROD climbing to FL060 or above.

RUSEB 1B

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 360° MAG to intercept QDR 311° W, then proceed on QDR 311° W to RUSEB climbing to FL060 or above.

SUGIP 1B

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on QDR 132° W to SUGIP climbing to FL060 or above.

STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 35

ABNIS 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 211° до захвата МПС 150° W, далее на ABNIS с МПС 150° W с набором FL060 или выше.

BAGOD 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 211° до захвата МПС 143° W, далее на BAGOD с МПС 143° W с набором FL060 или выше.

BALUS 1D

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 141° до захвата МПС 210° W, далее на BALUS с МПС 210° W с набором FL060 или выше.

DEDOR 1D

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 207° до захвата МПС 268° W, далее на DEDOR с МПС 268° W с набором FL060 или выше.

FADRI 1D

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 305° до захвата МПС 336° W, далее на FADRI с МПС 336° W с набором FL060 или выше.

GILAG 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 202° до захвата МПС 123° W, далее на GILAG с МПС 123° W с набором FL060 или выше.

INDIR 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 187° до захвата МПС 115° W, далее на INDIR с МПС 115° W с набором FL060 или выше.

NERDA 1D

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 141° до захвата МПС 217° W, далее на NERDA с МПС 217° W с набором FL060 или выше.

OGONI 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на БПРМ W, далее на OGONI с МПС 175° W с набором FL060 или выше.

PELIM 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 042° до захвата МПС 012° W, далее на PELIM с МПС 012° W с набором FL060 или выше.

PIROD 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 149° до захвата МПС 084° W, далее на PIROD с МПС 084° W с набором FL060 или выше.

RUSEB 1D

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 280° до захвата МПС 311° W, далее на RUSEB с МПС 311° W с набором FL060 или выше.

SUGIP 1D

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 202° до захвата МПС 132° W, далее на SUGIP с МПС 132° W с набором FL060 или выше.

ABNIS 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 211° MAG to intercept QDR 150° W, then proceed on QDR 150° W to ABNIS climbing to FL060 or above.

BAGOD 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 211° MAG to intercept QDR 143° W, then proceed on QDR 143° W to BAGOD climbing to FL060 or above.

BALUS 1D

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 141° MAG to intercept QDR 210° W, then proceed on QDR 210° W to BALUS climbing to FL060 or above.

DEDOR 1D

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 207° MAG to intercept QDR 268° W, then proceed on QDR 268° W to DEDOR climbing to FL060 or above.

FADRI 1D

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 305° MAG to intercept QDR 336° W, then proceed on QDR 336° W to FADRI climbing to FL060 or above.

GILAG 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 202° MAG to intercept QDR 123° W, then proceed on QDR 123° W to GILAG climbing to FL060 or above.

INDIR 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 187° MAG to intercept QDR 115° W, then proceed on QDR 115° W to INDIR climbing to FL060 or above.

NERDA 1D

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 141° MAG to intercept QDR 217° W, then proceed on QDR 217° W to NERDA climbing to FL060 or above.

OGONI 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT to LMM W, then proceed on QDR 175° W to OGONI climbing to FL060 or above.

PELIM 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 042° MAG to intercept QDR 012° W, then proceed on QDR 012° W to PELIM climbing to FL060 or above.

PIROD 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 149° MAG to intercept QDR 084° W, then proceed on QDR 084° W to PIROD climbing to FL060 or above.

RUSEB 1D

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 280° MAG to intercept QDR 311° W, then proceed on QDR 311° W to RUSEB climbing to FL060 or above.

SUGIP 1D

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 202° MAG to intercept QDR 132° W, then proceed on QDR 132° W to SUGIP climbing to FL060 or above.

STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 17

ABNIS 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на ABNIS с R152° PLR с набором FL060 или выше.

BAGOD 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на BAGOD с R146° PLR с набором FL060 или выше.

BALUS 1C

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на BALUS с R206° PLR с набором FL060 или выше.

DEDOR 1C

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 315° до захвата R261° PLR, далее на DEDOR с R261° PLR с набором FL060 или выше.

FADRI 1C

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 031° до захвата R333° PLR, далее на FADRI с R333° PLR с набором FL060 или выше.

GILAG 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 099° до захвата R128° PLR, далее на GILAG с R128° PLR с набором FL060 или выше.

INDIR 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 087° до захвата R120° PLR, далее на INDIR с R120° PLR с набором FL060 или выше.

NERDA 1C

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на NERDA с R213° PLR с набором FL060 или выше.

OGONI 1C

На МПУ 173° набор (200) или выше, далее на OGONI с R175° PLR с набором FL060 или выше.

PELIM 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 318° до захвата R014° PLR, далее на PELIM с R014° PLR с набором FL060 или выше.

PIROD 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 040° до захвата R091° PLR, далее на PIROD с R091° PLR с набором FL060 или выше.

RUSEB 1C

На МПУ 173° набор (200) или выше, ПРАВЫЙ разворот на МПУ 011° до захвата R307° PLR, далее на RUSEB с R307° PLR с набором FL060 или выше.

SUGIP 1C

На МПУ 173° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 099° до захвата R136° PLR, далее на SUGIP с R136° PLR с набором FL060 или выше.

ABNIS 1C

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on R152° PLR to ABNIS climbing to FL060 or above.

BAGOD 1C

Climb on track 173° MAG to (200) m or above, turn LEFT and proceed on R146° PLR to BAGOD climbing to FL060 or above.

BALUS 1C

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on R206° PLR to BALUS climbing to FL060 or above.

DEDOR 1C

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 315° MAG to intercept R261° PLR, then proceed on R261° PLR to DEDOR climbing to FL060 or above.

FADRI 1C

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 031° MAG to intercept R333° PLR, then proceed on R333° PLR to FADRI climbing to FL060 or above.

GILAG 1C

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 099° MAG to intercept R128° PLR, then proceed on R128° PLR to GILAG climbing to FL060 or above.

INDIR 1C

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 087° MAG to intercept R120° PLR, then proceed on R120° PLR to INDIR climbing to FL060 or above.

NERDA 1C

Climb on track 173° MAG to (200) m or above, turn RIGHT and proceed on R213° PLR to NERDA climbing to FL060 or above.

OGONI 1C

Climb on track 173° MAG to (200) m or above, then proceed on R175° PLR to OGONI climbing to FL060 or above.

PELIM 1C

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 318° MAG to intercept R014° PLR, then proceed on R014° PLR to PELIM climbing to FL060 or above.

PIROD 1C

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 040° MAG to intercept R091° PLR, then proceed on R091° PLR to PIROD climbing to FL060 or above.

RUSEB 1C

Climb on track 173° MAG to (200) m or above, turn RIGHT onto track 011° MAG to intercept R307° PLR, then proceed on R307° PLR to RUSEB climbing to FL060 or above.

SUGIP 1C

Climb on track 173° MAG to (200) m or above, turn LEFT onto track 099° MAG to intercept R136° PLR, then proceed on R136° PLR to SUGIP climbing to FL060 or above.

STANDARD DEPARTURE ROUTES INSTRUMENT – (SID)

POLIARNY, RUSSIA
POLIARNY
RWY 35

ABNIS 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 204° до захвата R152° PLR, далее на ABNIS с R152° PLR с набором FL060 или выше.

BAGOD 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 204° до захвата R146° PLR, далее на BAGOD с R146° PLR с набором FL060 или выше.

BALUS 1F

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 151° до захвата R206° PLR, далее на BALUS с R206° PLR с набором FL060 или выше.

DEDOR 1F

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 218° до захвата R261° PLR, далее на DEDOR с R261° PLR с набором FL060 или выше.

FADRI 1F

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на FADRI с R333° PLR с набором FL060 или выше.

GILAG 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 190° до захвата R128° PLR, далее на GILAG с R128° PLR с набором FL060 или выше.

INDIR 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 173° до захвата R120° PLR, далее на INDIR с R120° PLR с набором FL060 или выше.

NERDA 1F

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 151° до захвата R213° PLR, далее на NERDA с R213° PLR с набором FL060 или выше.

OGONI 1F

На МПУ 353° набор до D7.0 PLR, ПРАВЫЙ разворот на VORDME PLR, далее на OGONI с R175° PLR с набором FL060 или выше.

PELIM 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 044° до захвата R014° PLR, далее на PELIM с R014° PLR с набором FL060 или выше.

PIROD 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 136° до захвата R091° PLR, далее на PIROD с R091° PLR с набором FL060 или выше.

RUSEB 1F

На МПУ 353° набор (200) или выше, ЛЕВЫЙ разворот на МПУ 276° до захвата R307° PLR, далее на RUSEB с R307° PLR с набором FL060 или выше.

SUGIP 1F

На МПУ 353° набор (200) или выше, ПРАВЫЙ разворот на МПУ 190° до захвата R136° PLR, далее на SUGIP с R136° PLR с набором FL060 или выше.

ABNIS 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 204° MAG to intercept R152° PLR, then proceed on R152° PLR to ABNIS climbing to FL060 or above.

BAGOD 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 204° MAG to intercept R146° PLR, then proceed on R146° PLR to BAGOD climbing to FL060 or above.

BALUS 1F

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 151° MAG to intercept R206° PLR, then proceed on R206° PLR to BALUS climbing to FL060 or above.

DEDOR 1F

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 218° MAG to intercept R261° PLR, then proceed on R261° PLR to DEDOR climbing to FL060 or above.

FADRI 1F

Climb on track 353° MAG to (200) m or above, turn LEFT and proceed on R333° PLR to FADRI climbing to FL060 or above.

GILAG 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 190° MAG to intercept R128° PLR, then proceed on R128° PLR to GILAG climbing to FL060 or above.

INDIR 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 173° MAG to intercept R120° PLR, then proceed on R120° PLR to INDIR climbing to FL060 or above.

NERDA 1F

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 151° MAG to intercept R213° PLR, then proceed on R213° PLR to NERDA climbing to FL060 or above.

OGONI 1F

Climb on track 353° MAG to D7.0 PLR, turn RIGHT to VORDME PLR, then proceed on R175° PLR to OGONI climbing to FL060 or above.

PELIM 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 044° MAG to intercept R014° PLR, then proceed on R014° PLR to PELIM climbing to FL060 or above.

PIROD 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 136° MAG to intercept R091° PLR, then proceed on R091° PLR to PIROD climbing to FL060 or above.

RUSEB 1F

Climb on track 353° MAG to (200) m or above, turn LEFT onto track 276° MAG to intercept R307° PLR, then proceed on R307° PLR to RUSEB climbing to FL060 or above.

SUGIP 1F

Climb on track 353° MAG to (200) m or above, turn RIGHT onto track 190° MAG to intercept R136° PLR, then proceed on R136° PLR to SUGIP climbing to FL060 or above.