STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL: ❶

NYAGAN, RUSSIA
NYAGAN
RWY 16



TOWER **122.300**

WARNING
TAR reads zero at ARP.

❶ TRANSITION LEVEL:
- FL050 when QFE is 760mm mercury column (1013 hPa) or above;
- FL060 when QFE is less then 760mm mercury column (1013 hPa), but 733mm mercury column (977 hPa) or above;
- FL070 when QFE is less then 733mm mercury column (977 hPa).

BEARINGS AND TRACKS ARE MAGNETIC HEIGHTS IN METRES ALTITUDES IN ***FEET*** ELEVATIONS IN METRES AND ***FEET*** DISTANCES IN KILOMETRES	Alt set: - QFE (QNH on req); - mm (hPa on req).

CHANGE: New chart