STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

NADYM, RUSSIA
NADYM
RWY 32



RADAR **135.400**
START **120.600**

❶ TRANSITION LEVEL:
- FL040 when QFE is 751mm mercury column or above (1001 hPa);
- FL050 when QFE is less than 751mm mercury column (1001 hPa).

NOTE
TAR distance is indicated from ARP.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN ***FEET***, HEIGHTS IN METRES
ELEVATIONS IN METRES AND ***FEET***
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: COM