VFR
ARRIVAL
CHART

TRANSITION
LEVEL: ❶

NOVY URENGOY, RUSSIA

NOVY URENGOY
RWY 09



RADAR	**124.700**
TOWER	**121.900**

❶ TRANSITION LEVEL:
- FL060 when QNH is 1013 hPa (760mm mercury column) or above;
- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL080 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN ***FEET***
ELEVATIONS IN ***FEET*** AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: COM