STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL: ❶

IVANOVO, RUSSIA
YUZHNY
RWY 29



IVANOVO VYSHKA **127.100**

❶ TRANSITION LEVEL:
- FL060 when QNH is 1013 hPa (760mm mercury column) or above;
- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL080 when QNH is less than 977 hPa (733mm mercury column).

WARNING
Control of passing the turning point of the route - by ATS unit instruction.

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN ***FEET*** HEIGHTS IN METRES DISTANCES IN KILOMETRES	Alt set: -QNH(QFE on req); -hPa(mm on req).

CHANGE: MSAAT/MSHAT