


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

SYKTYVKAR, RUSSIA
SYKTYVKAR
RWY 36

TRANSITION
LEVEL: ①



SIVKAR KRUG 124.600

- ① TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL050 when QNH is 977 hPa (733mm mercury column) or above but less than 1013 hPa (760mm mercury column);
 - FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES