



TRANSITION LEVEL:
 - FL110 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL120 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL130 when QNH is less than 977 hPa (733mm mercury column).

RW	32L	32R
Feet (QNH)	Metres (QFE)	Metres (QFE)
3300	(845)	(850)
3000	(755)	(755)
2000	(450)	(450)

MOSCOW, RUSSIA
DOMODEDOVO
RNAV RWY 32R, 32L

MOSCOW APPROACH DOMODEDOVO ARRIVAL	Sector A6	Sector A8	Sector DD1	Sector DD2	TOWER	TOWER
	125.300	129.800	127.700	119.400	118.600	119.700

See AD 2.1 UDD-55

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES

SCALE 1 : 500 000



MOSCOW, RUSSIA
DOMODEDOVO
RNAV RWY 32R, 32L