


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

VLADIVOSTOK, RUSSIA  
KNEVICH I  
RNAV RWY 07R

TRANSITION  
LEVEL: 1



2 MSAAT/MSHAT is computed for surface air temperature at the aerodrome -33°C.

3 MNM 2600'/(785) VATIS 2M

VLADIVOSTOK RADAR 123.400  
VLADIVOSTOK TOWER 119.500

- 1 TRANSITION LEVEL:
- FL080 when QNH is 1013 hPa (760mm mercury column) or above;
  - FL090 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
  - FL100 when QNH is less than 977 hPa (733mm mercury column).
- 3 Holding procedure shall be executed by arrangement with ATS unit, when UHR1493 is active.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES IN FEET  
HEIGHTS IN METRES  
ELEVATIONS IN FEET AND METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).

CHANGE: MSAAT/MSHAT