



INSTRUMENT
APPROACH
CHART - ICAO

INFORMATSIYA 126.000

BOVANENKOVO, RUSSIA
BOVANENKOVO
RNAV RWY 28



DIST to RW28	2.0	4.0	6.0	7.8
ALTITUDE/HEIGHT	430'/(125)	770'/(230)	1120'/(335)	1430'/(430)



OCA(H)		A	B	C	D	1 TRANSITION LEVEL:					
Straight-in Approach	LNAV	380' (360') (110)	380' (360') (110)	380' (360') (110)	380' (360') (110)	- FL060 when QNH is 1013 hPa (760mm mercury column) or above;					
	LNAV/VNAV	210' (190') (60)	220' (200') (60)	250' (230') (70)	290' (270') (85)	- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);					
Circling		460' (440') (135)	520' (500') (155)	660' (640') (195)	720' (700') (215)	- FL080 when QNH is less than 977 hPa (733mm mercury column).					
GROUND SPEED		km/h	150	180	210	240	270	300	330	360	390
RATE OF DESCENT		m/s	2.2	2.6	3.1	3.5	3.9	4.4	4.8	5.2	5.6
		ft/min	427	512	597	682	768	853	938	1024	1109